

## Sending and Receiving Triggers with External Devices

- 1) What port communications are supported in E-Prime 2.0?
  - Parallel
  - Serial
  - Ethernet (Socket)
  
- 2) How do I find the port address?
  - Device manager for the Parallel and Serial devices
  - Command Prompt to find the Socket device IP address
  
- 3) Parallel Communications
  - What to do on a machine without a Parallel Port
    1. Where to find more information on compatible devices
    2. When to use the Port vs. ParallelPort Device
  - Sending triggers using InLine script
    1. Trigger at onset and offset
    2. WritePort and ReadPort
  
- 4) Serial Communications
  - What to do on a machine without a Serial Port
  - Sending triggers using InLine script
    1. Trigger after objects
    2. Trigger during objects
  
- 5) Socket (i.e. Ethernet) Communications
  - Sending triggers using InLine script
    1. Similar to Serial Device
  
- 6) Task Events
  - Sending triggers without script
  - Explanation of Data Types
  
- 7) Support available from [www.pstnet.com/support](http://www.pstnet.com/support)

Q&A